Dell Wired Headset

WH125

User's Guide





Regulatory model: HS2201

- (i) NOTE: A NOTE indicates important informa tion that helps you make better use of you rcomputer.
- ▲ CAUTION: A CAUTION indicates potential damage to hardware or loss of data if instructions are not followed.
- **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

© 2025 Dell Inc. or its subsidiaries. All rights reserved. Dell Technologies, Dell, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

2025-03

Rev. A00

Contents

What's in the box	4
Features	5
Specifications	6
Setting up the headset	7
Headband & microphone boom fit	8
Buttons and indicator light	9
Regulatory and PPID label	10
Frequently asked questions	11
Troubleshooting	12
Statutory information	13
Getting help	14

What's in the box



Features

Headset



Specifications

Specifications	Value
Headset dimension	155 mm x 168.60 mm x 59.80 mm
Earpads dimensions	59.80 mm x 59.80 mm x 16.50 mm
Operating Voltage	3~5.50 V
System requirements	Windows 10 or latest MacOS 10.7 or latest Linux
Speaker Sensitivity	117±3dB
Speaker frequency range	20Hz~20KHz
Microphone Sensitivity	-46±3dBV/Pa
Microphone frequency range	100Hz~10KHz
MIC boom	270° rotational
Boom Mic Feature & Behavior	Flexible boom mic

Setting up the headset



Connect the headset controller cable to a USB-A port on your laptop or desktop.





Headband & microphone boom fit

Headband fit

Adjust headset by sliding headband up or down.



Microphone boom fit

- 1. Microphone boom rotates to 270 degree to left or right (figure 1).
- 2. Adjust flexible microphone boom angle (figure 2).



Buttons and indicator light

Button	Usage		Indicator Light	Action
<u>*</u>	Microphone	Mute	Microphone	Short press to Mute
		Unmute	No Light	Short press to Unmute
+				Short press to increase volume
-	Volume		No Light	Short press to decrease volume
-	Speaker Volume	Turn on volume	No Light	Short press to turn volume on/off
4 10		Turn off volume		
المعالم المعالم Mute + Speaker volume on		The receiver is unable to hear the user, but the user can hear the receiver		
Unmute + Speaker volume off		The receiver can hear the user, but the user is unable to hear the receiver		
Mute + Speaker volume off		Both user and receiver are unable to hear each other		
Unmute + Speaker volume on		Both user and receiver can hear each other		



Regulatory and PPID label

NOTE: The following image is a sample illustration to show the regulatory label location only.



Frequently asked questions

1. How do I know if my headset is on?

The Dell WH125 headset has a status-LED on the controller that stays on (green light) when the headset is in use. The status-LED behavior is as follows: Headset is on - Status LED is solid green Headset is off - No light

2. How to handle and maximize product shelf life?

Proper Adjustment: When adjusting the size or fit of the headset, do so with care and avoid applying excessive pressure or pulling forcefully on the extender.

Stretch the Headband: If your headset is new, they might be a bit stiff and exert too much clamping force. Gently stretching (max 260 mm) the headset to help reduce this force. Or when not in use, place the headset on another object that is slightly larger than your head. It can help to gradually reduce the clamping force over time.

Avoid Dropping: Be cautious not to drop the headset. Place the headset on a secure surface when not in use and avoid placing heavy objects on top of it.

Transport Safely: When traveling with the headset, it is recommended to use a protective case or bag. It helps safeguard the headset from impact, scratches, and other potential damage during transportation.

Cable Management: Take care when handling the cables. Avoid bending them excessively or twisting them tightly, as it can strain the connectors and potentially lead to damage. Handle the cables gently and avoid tugging or pulling them forcefully.

Storage: When not in use, store the headset in a clean and dry environment. Keep it away from extreme temperatures, humidity, or direct sunlight, as these conditions can affect its performance and durability.

 \triangle **CAUTION:** Applying excessive force to extend the headset beyond 260 mm may result in damage or breakage.



Troubleshooting

Problem	Possible solutions
No audio from headset	 Unplug and reconnect the headset to the computer. Test on an alternate device if available.
Echo heard from the microphone	 Adjust the volume on your computer. Adjust the microphone boom so that it is not too close to your mouth.
Audio issues	 Adjust microphone closer to your mouth. Adjust the microphone volume on the adapter or adjust the microphone type on the selected adapter. Unplug and reconnect the headset to check again.
Computer speakers playing audio despite having the headset plugged in.	Check the "Setting>System>Sound>Select Output Device" and select "DELL Wired Headset".

Statutory information

Warranty

Limited warranty and return policies

Dell WH125 headset ships with a 3-years limited hardware warranty. If purchased together with a Dell computer, it follows the computer warranty.

For U.S. customers:

This purchase and use of this product is subject to Dell's end user agreement, which is available at **Dell.com**. This document contains a binding arbitration clause.

For European, Middle Eastern and African customers:

Dell-branded products that are sold and used are subject to applicable national consumer legal rights, the terms of any retailer sale agreement that you have entered into (which will apply between you and the retailer), and Dell's end user contract terms. Dell also provides an additional hardware warranty. More details of the Dell end user contract and warranty terms can be found in **Dell.com.** Select your country or region from the list at the bottom of the "home page" and then click the "terms and conditions" link for the end user terms.

For non-U.S. customers:

Dell-branded products that are sold and used are subject to applicable national consumer legal rights, the terms of any retailer sale agreement that you have entered into (which will apply between you and the retailer), and Dell's end user contract terms.

Dell also provides an additional hardware warranty. More details of the Dell end user contract and warranty terms can be found in **Dell.com.** Select your country or region from the list at the bottom of the "home page" and then click the "terms and conditions" link for the end user terms or the "support link" for the warranty terms.

Safety Information

Keep the volume at optimal levels while in use.

Do not listen at high volume levels for a long period. Prolonged exposure to a high volume may cause a high sound pressure and may cause a risk of hearing damage.

Getting help

Contacting Dell

NOTE: If you do not have an active Internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.

Dell provides several online and telephone-based support and service options.

Availability varies by country and product, and some services may not be available in your area. To contact Dell for sales, technical support, or customer service issues:

Steps

- 1. Go to Dell.com/support.
- 2. Select your support category.
- 3. Verify your country or region in the Choose a Country/Region drop-down list at the bottom of the page.
- 4. Select the appropriate service or support link based on your need.